



Ready-to-use cleaner for sealed wood floors prior to recoating or for tacking operations

Advantages:

- Properly diluted product ensures well prepared floors
- Lifts soils from the pores of the existing coating
- No draining recovery tank filled with foam
- Cleaner residue will not stick to floor
- No lengthy clean-up
- Should **Screen Clean** dry on floors, it easily “re-activates” once scrubbed/rinsed for easy removal
- Tacking with **Screen Clean** will leave sealed wood sports floor clean and ready for play

Coverage:

- 300-400 square feet per gallon

Features:

- A fast dry, no residue tacking solution suitable for all sealed wood floors
- Suitable for tacking operations during floor prep for re-coating and for cleaning dirty/slippery floors on previously coated wood floors
- Ready-to-use cleaner
- Effectively removes dirt and soil during wet screen process
- Low-foaming
- Free rinsing
- No dust
- Easily “re-activated”
- Safe on floor coating
- May be applied with an EZ-Way applicator, sprinkling can, mop and bucket, or cotton bath towels

Available in:

5-gallon
Action
Pacs®

DIRECTIONS

Directions for Screening:

1. Dust mop floor to remove grit and debris. Remove any gum and tape.
2. Apply **Screen Clean** to the floor using an EZ-Way applicator, sprinkling can or mop and bucket. Wet a section approximately 200 square feet.
3. Screen with a rotary swing machine equipped with white or red pad and #120 grit screen. Soak all new screens with **Screen Clean** prior to use. The white pad helps hold the screen to the pad driver. Scrub the 200 square foot area twice (once moving north/south going slowly with the boards, then a second pass going east/west – you can move faster on this pass). As you're screening, overlap the previous pass by half the width of the screen in order to avoid missing any areas.
4. Pick up the dirty solution and rinse well. Wet vacuums and mops and buckets can be used; however, an autoscrubber filled with plain water and equipped with a red or blue pad works much better.
5. Wet the next 200 square foot section, flip the screen over and repeat the process (one scrub north/south, again east/west).
6. For the next 200 square foot section, begin with a fresh screen. Each screen is good for 400 square feet (200 per side).
7. If you have an autoscrubber, after the entire floor has been screened and rinsed, scrub/rinse the entire floor once more with plain water – use blue or red pads.
8. Finally tack entire floor using white cotton bath towels moistened with **Screen Clean**.
9. Allow floor to dry thoroughly.
10. Apply the Buckeye Reflections® coating according to manufacturers instructions.

Directions for Tacking:

To clean floor and/or to fix slippery floors:

1. Soak a white cotton bath towel with **Screen Clean**.
2. Wring out until no longer dripping.
3. Wrap around a clean push broom and push across the floor.
4. Re-position the broom to different areas of the towel after each pass, and flip the towel after one side is dirty.
5. Change out to a clean towel as needed.
6. Allow floor to dry completely before resuming play or before recoating floor.

Technical Specifications:

Actives	3.25%
pH Concentrate	9.0 ± 0.5
Weight/Gallon	8.33 lbs
Flash Point	None
Fragrance	Lemon Lime
Color	Light Blue/Green
Abrasives	None
EDTA – Phosphates	None
Biodegradable	Yes



Buckeye International, Inc.

2700 Wagner Place • Maryland Heights • MO 63043
800.321.2583 • www.buckeyereflections.com